

# MICCRO<sup>®</sup> PRODUCTS

## TECHNICAL INFORMATION DATA

# MICCROTEX<sup>®</sup>



MICCROTEX<sup>®</sup> Air-Dry Rack Coating is a superior thermoplastic insulating material highly resistant to all plating solutions, acids, and alkaline cleaners at boiling temperatures.

### **APPLICATION PROCEDURE**

#### **MICCROTEX SHOULD BE STIRRED PRIOR TO USAGE**

MICCROTEX<sup>®</sup> is more successfully applied by dipping; this method should be applied wherever possible. Under certain conditions, however, brushing or spraying may also obtain satisfactory results. For most effective application, MICCROTEX<sup>®</sup> should be maintained at room temperature (70°F to 80°F). For dipping and brushing MICCROTEX<sup>®</sup> is used as shipped. For spraying MICCROTEX<sup>®</sup>, reduce three parts of MICCROTEX<sup>®</sup> with two parts of MICCRO<sup>®</sup> REDUCER.

**PREPARATION OF RACKS:** All racks should be thoroughly cleaned of all grease, dirt and loose oxides. Sandblasting or an electrolytic caustic cleaning cycle with thorough drying is recommended. Aluminum racks should be anodized before coating. Filing or grinding should round all sharp edges or corners.

**DIPPING PROCEDURE:** Rack should be lowered slowly, allowing approximately one minute for complete submersion. Move rack back and forth—this will shake off all air bubbles and eliminate air pockets. Allow rack to remain submerged a few seconds, and then withdraw at the same speed. Drain for one or two minutes over dip tank. After draining, invert rack and suspend from opposite end to assure an even distribution of the coating and to eliminate beading. Normally at least seven coats are required.

**DRYING:** Allow at least one-hour air-dry at room temperature (70°F to 80°F) to each coat, and twenty-four hour air-dry for the final coat. Under extreme conditions it is advisable to force-dry at 160°F to 180°F for 4 to 6 hours after the final coat is applied.

**CONTACT POINTS:** To bare contact points cut through coating with a sharp knife (do not tear). Seal cut edges by brushing with one coat of MICCROTEX<sup>®</sup>. Dry for two hours before using.

**REPAIRING RACKS:** Damaged racks may be repaired without re-dipping the entire rack. Cut away all loose material and remove any projecting nodules or electrolytic deposits—dry thoroughly before repairing. Flow succeeding coats of MICCROTEX<sup>®</sup> over bare spot until the material has been built up to its original thickness. Air-dry at least one hour between coats and twenty-four hours after final coat.

*Available in 1 gallon, 5 gallon and 55 gallon containers*

**TOLBER<sup>®</sup>**  
PROVEN SOLUTIONS

220 WEST 5TH STREET, HOPE, ARKANSAS 71801  
PH: (870) 777-3251 • FAX: (870) 777-8056 • [www.TOLBER.com](http://www.TOLBER.com)