

MICCRO[®] PRODUCTS

TECHNICAL INFORMATION DATA

MICCROSTRIP[®] A



One-Step Coatings Removal Performance
Similar to MEK and Methylene Chloride

APPLICATION PROCEDURE

MICCROSTRIP[®] A SHOULD BE STIRRED PRIOR TO USAGE

MICCROSTRIP[®] A is specifically designed for the removal of Stop-off Lacquers. The items to be stripped should be fully immersed in MICCROSTRIP[®] A at room temperature for a period of time long enough to dissolve the lacquer. NOTE: Mechanical agitation will decrease the already quick removal time.

MICCROSTRIP[®] A is a volatile solvent. Operators should therefore be cautioned against handling this material without proper safety equipment. In the event it is splashed in the eyes, wash immediately with water and consult with medical personnel as soon as possible. Adequate ventilation should be provided to prevent excessive inhalation of vapors. This material should be stored in a cool place.

NOTE: Flammable material, keep away from open flames. MICCROSTRIP[®] A should never be used as a lacquer thinner.

Available in 1 gallon, 5 gallon and 55 gallon containers



220 WEST 5TH STREET, HOPE, ARKANSAS 71801
PH: (870) 777-3251 • FAX: (870) 777-8056 • www.TOLBER.com